



ESC	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12	○
~ '	! 1	@ 2	# 3	\$ 4	% 5	^ 6	& 7	* 8	(9) 0	- _	+ =	⊠
TAB	Q	W	E	R	T	Y	U	I	O	P	{ [}]	 \
CTRL	⋮ _	A	S	D	F	G	H	J	K	L	: ;	" ,	ENTER
⇧	DEL	Z	X	C	V	B	N	M	< ,	> .	? /	↑	⇧
HYPER	⚡	CTRL		ALT	ALT				⬆	⬇	←	↓	→

